

RAVEN EYE CUSTOM

SMITH AND WESSON MP15-22[©]

MAGAZINE SPEEDLOADER KIT

INSTALLATION INSTRUCTIONS - SHEET 1 OF 1

READ PRIOR TO INSTALLATION

MAKE SURE YOUR FIREARM IS UNLOADED BEFORE DOING ANY WORK ON IT.

As the end user and installer of this product, you must accept full responsibility for the correct installation of this product and the resulting condition of your firearm. If you are unwilling to accept this, return the product to the address listed below for a full refund. If you are unable to install this product, seek the services of a qualified gunsmith, or send us an email to the address listed below and we can assist you.

Step 1 Use the supplied key to depress the button on the floorplate.
(Note - if you are replacing extra loading buttons only, the kit does not contain the loading key or cap)

Step 2 Carefully slide out the floorplate. Keep tension on the spring until the spring can be safely removed. Otherwise it will cause an unsafe condition and eject out.

Step 3 Lower the follower (red piece) to the bottom of the magazine and slide out the loading button. Replace with the new loading button. Re-assemble the magazine by following steps 1-3 in reverse.

Step 4 Insert loading key into the new loading assist button. Put key cap on other side. When loading is complete, remove the key and cap.



NOTE: Additional loading assist buttons are available for purchase.

BE SAFE!

RAVEN EYE CUSTOM

www.RavenEyeCustom.com
P.O. BOX 150083 LAKEWOOD COLORADO 80215
info@raveneyecustom.com

Copyright 2011
Revised September 9, 2011

